




Pet Water Fountain

Model: W03 Lite



USER MANUAL

* Before using the product, please read this manual thoroughly and retain it for future reference.

Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.

[CONTENTS]

SAFETY INSTRUCTIONS	1
Warning	1
Caution	2
Note	3
PRODUCT OVERVIEW	4
HOW TO USE	5
WATER PUMP INDICATOR LIGHT STATUS	7
CARE INSTRUCTIONS	8
Replace the filter	8
How to clean the pump	8
SPECIFICATION PARAMETERS	9
FAQs	10
ASK US A QUESTION	11
WARRANTY INFORMATION	13

SAFETY INSTRUCTIONS

▲ WARNING

- Please choose DC5V-1A adapters in line with relevant national and regional standards to avoid any possible damages or safety hazards.

- Do NOT place any foreign object into the water tank.

- Only use attachments recommended or sold by WOpet. Using attachments from other manufacturers may create unsafe conditions.

- Do NOT modify the structure or electrical components of the pet fountain yourself.

- Do NOT operate the appliance if it is malfunctioning or has been damaged. Avoid attempting repairs on your own. Instead, contact our customer service immediately for further assistance.

- For safety, disconnect the power supply when the appliance is not in use.

- Always unplug the appliance when not in use, and before attaching, removing, or cleaning any parts.

- Do not allow the power adapter or plug to get wet during cleaning.

- This product is intended for indoor use only.

- Do not operate this product without water.

- Never pull the power cord to unplug the device from the wall outlet.

- If the plug becomes wet, turn off the power to that outlet immediately. Do NOT attempt to unplug.

- Replace the filter when water flow significantly decreases. If you have two or more cats, you may need to change the filter more frequently if it becomes clogged.

CAUTION

Do NOT allow pets to chew on or swallow any parts.

If an extension cord is needed, use one with the appropriate power rating.

Do NOT install or store the pet water fountain in areas exposed to weather or temperatures below 0°C (40°F).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299


CARE INSTRUCTIONS

REPLACE THE FILTER

Primary Filter Cotton: Replaced every 1-2 weeks in normal cases.

Columnar Core Filter: Replaced every 2-4 weeks in normal cases.

* It's recommended to replace the filter every two weeks when it's shared by multiple pets.



Primary Filter Cotton




Columnar Core Filter

HOW TO CLEAN THE PUMP


1. Remove the foam filter, pump cover and impeller cover in sequence.

Note:


The foam filter significantly affects water flow, so please clean it regularly and replace it as needed when cleaning the pump.



2. Remove the impeller by the brush hook.



3. Use the brush to clean the parts with water.



Tip: The brush can also be used to clean the spout. Recommended to clean the spout every 2 weeks.

SPECIFICATION PARAMETERS

Product Name	Pet Water Fountain
Dimension	9.25 x 9.25 x 6.3 in
Rated Voltage / Current	DC 5V/1A
Rated Power	0.325W
Capacity	3L (101 OZ)
Material	ABS + Ceramic

FAQS

Q: The water fountain does not work.

A: 1. Use a compliant 5V/1A adapter and correctly plug the Type-c cable and adapter.
2. If the water pump is not working, please try using a mobile phone charger or power bank to supply power.

Q: The water pump shows a red indicator light.

A: 1. The water level is too low; please add more water.
2. Clean the filter cotton and impeller at the water pump.

Q: Water output speed slows down.

A: 1. For the first use (or reuse after long-time storage), the water pump needs to discharge air, it's normal if the water output speed slows down.
2. There may be dirt in the pump. Please refer to the "How to Clean the Pump" section in the manual for cleaning instructions.

Q: Black residues and dirt appear in the water tank and on the filter element.

A: 1. Ensure the water source is replaced regularly with clean water.
2. Rinse the filter element before use.

For more questions, please email our support team:

support@wopet.com



Scan the QR code to get help

ASK US A QUESTION

1.Find your order

Home

Your Order

Buy Again

Your Wish List

Your Account

Shop by Department >

2.Click "View order details"

Your Orders

Product link

Buy it again >

Write a product review >

View order details >

3.Click the Seller name

View order details

Order#

Order Total

Shipped

Product link

Qty: 1

Sold By: Seller

4.Click "Ask a question"

BRAND

Have a question
for the seller?

Ask a question

● Complimentary parts, replacements, consumable products are not covered by the 2-year warranty.

● Manufactures' warranties may not apply in all cases, depending on factors such as use of the product, where the product was purchased, or who you purchase the product from.

● Please review the warranty carefully, and contact the manufacture if you have any questions.

WARRANTY INFORMATION

● If you have any problems when using our products, please send us an email at support@wopet.com

● 30 days free Return & Replacement

● Standard Warranty: 1-Year product
Warranty 2-Year Warranty Application:
Please scan the QR code to finish the
registration form on our official website
within 30 days after you received the items.



Pet First, One Paw At A Time.