


8L
LARGE DOG WATER FOUNTAIN
User Manual



MADE IN CHINA
MODEL: A08


WARNING

1. When children use this product, please use it under the supervision of parents.
2. To prevent electric shock, do not immerse the power cord or plug in water.
3. Be sure to cut off the power before not using electrical appliances, or installing, or cleaning.
4. Please keep changing the filter element at least every two weeks.
5. Please keep the water pump cleaned at least once every two weeks.
6. Before adding water, or restarting the pump after cleaning, please turn off the power first.
7. Do not let pets chew or swallow any part. If you are concerned about the power cord, purchase wire guides (hard plastic protectors) at any hardware store to protect the power cord.
8. If the device is faulty or damaged, do not try to repair the pet water dispenser by yourself, contact us immediately to solve it.
9. Most pets are sensitive, and some pets may not be able to accept the water dispenser immediately. Please keep it at home for a few days and guide the pet to use it.

DIRECTORY

ACCESSORIES LIST	1
ASSEMBLY AND USE	2
TIPS	3
DISASSEMBLE AND CLEAN	4
MAKING A CLAIM	6
SPECIFICATION	7

ACCESSORIES LIST



- | | |
|------------------------|--------------------------------|
| 1 The Faucet×1 | 7 Water Guide Silicone Tube×1 |
| 2 Water Cover×1 | 8 Wired Water Pump×1 |
| 3 Water Storage Tank×1 | 9 Adapter×1 |
| 4 Filter Upper Cover×1 | 10 User Manual×1 |
| 5 Filter Element×1 | 11 Water Pump Cleaning Brush×1 |
| 6 Filter Tray×1 | 12 Anti Slip Foot Mats×2 |

- 1 -

ASSEMBLY AND USE


1. Open the top cover
2. Install the water outlet
3. Install the water guide silicone tube
4. Install the water pump
5. The power cord of the water pump is buckled into the position of the power
6. The usb power cable is connected to the DC interface

- 2 -

7. Add the right amount of water
8. Install the top cover
9. Plug in power

TIPS

1. Filters element are rinsed for 30 seconds before use
2. It is recommended to replace the filter element every 1-2 weeks



- 3 -

DISASSEMBLE AND CLEAN

■ Disassemble the fountain

- 1) Remove the water outlet
- 2) Tilt the top cover until there is no water on the top cover
- 3) Open the top cover
- 4) Take out the filter element
- 5) Remove the water pump
- 6) Clean the water storage base

- 4 -

■ Clean the internal wall of water pump

- Step 1: Remove and clean the pump sponger.
- Step 2: Remove the pump cover.
- Step 3: Remove the impeller cap by the fingernail.
- Step 4: Clean the remaining part with the brush.

NOTICE:

1. To further ensure pets' health, it's highly recommended to increase the frequency of changing water and cleaning the fountain & pump, at least once a week.
2. Please replace the filter every 12 days in most cases, if you have more pets, or your pets are fond of playing with the drinking water, change the cat water filter proceeding from a real situation.

- 5 -

MAKING A CLAIM

- If you have any problems when using our products, please send an email to the mailbox: support@wopet.com

■ HAVE A QUESTION FOR THE SELLER?

1. Find your order
Home
Your Order
Buy Again
Your Wish List
Your Account
Shop by Department
2. Click"View order details"
Your Orders
Product link
Buy It again
Write a product review
View order details
3. Click the"Seller name"
View order details
Order #
Order Total
Shipped
Product link
Qty:1
Sold By: Seller
4. Click"Ask a question"
BRAND
Have a question for the seller?
Ask a question

- 6 -

SPECIFICATION

- Water Outlet Mode: A08
- Product Dimension: 9.5×5.9×14.8in/24.2×15×37.7cm
- Power Supply: DC 5V(Adapter of DC 5V-1A or 2A is recommend)
- Filter: Replaceable activated carbon filter element Product
- Product Weight: 1.4kg/3.1Lb
- Water Storage Capacity: 8.0L
- Dissipated Power: 1W

- 7 -