

Guardian WIFI Pet Camera Treat

Model: D01 Plus



USER MANUAL

[CONTENTS]

Product Specifications 1
Features and Indicators 2
WIFI Requirements 3
App Installation 4
App Usage
Add the Pet Camera Treat 5
Access the WLAN Network 6
WLAN Connection Modes7
App Interface Function Introduction 9
Switching Different Mode 13
Scan Mode14
AP Mode15
Manual Feed16
FAQS17
FCC Warnings
Warranty Information21
Have a Question?24

Product Specifications

Model	D01 Plus	
Food size	2-15mm (dry food only)	
Product size	L147*147*254mm/5.78*5.78*10in	
Product weight	1.1kg/2.42lbs	
Product material	ABS	
DC-powered supplp	5V/1A	
Network	5GHz/2.4GHz	

Features and Indicators



WIFI Requirements

• In order to optimize equipment performance, it's best to use it within 10m of a WIFI transmitting device in a barrier-free environment. WIFI

App Installation

- Download and install the APP by scanning the QR code below.
- For Andriod users, search "wopet smart" in Google Play store, For IOS users, search "WOPET" in the App store.
- Scan the QR code to download WOPET APP



Ap Usage

Step 1 Add the Pet Camera Treat



• Launch the "Wopet" App, then register an account and log in.

Note:

Each device can be attached to only one account at a time, but one account can have up to three devices connected.

 Choose the

 option to add a named D01 Plus device.

Note:

Make sure your phone is connected to WIFI with favorable network speeds.



STEP 2 Access the WLAN Network

• Press and hold the set button, then release it when the device makes a "Ding-Dong" sound. It will then display "restore successful" which means the machine has been reset.



Note:

Observe and wait for the indicator to blink green before selecting the connection mode in the next step

STEP 3 WLAN Connection Modes

Step 3.1 Bluetooth Mode (Recommended)

• Choose "Bluetooth Mode." In the next step, a pop up will prompt you to then turn on Bluetooth as in the description





• The app will automatically access WIFI from your phone; just type the correct password. Finally, click the "confirm" option and it will begin connecting.

Note:

If Bluetooth mode fails, please refer to the Scan mode or AP mode guide on page 14 and page 15



App Interface Function Introduction



• Click 💮 in the top right corner to enter the settings interface.





- You can set the device name, recording,volume etc.
- If you want to have voice interaction with your pet, you must enable the "Two-way voice" option.
- If the device is lacking food, you can check this notification in "Event List" option.

• Click (2) "Me" in the bottom right corner to enter the settings interface.





- Select the "Push" option, and you can receive a push notification when feeding is complete.
- You can also change your password on this page.
- Check the updates
- Close the account
- Log out the account

 If there is a question about your device, please click "" "help" enter next page below.





 Please refer to this page for solutions. For any other questions, please contact customer service via support@wopet.com

Switching Different Mode



 If the Bluetooth mode connection fails: Press and hold the "SET" button, then release it when the device makes a "Ding" sound. Wait for the indicator to slowly blink green, and then select one of the modes.

STEP 1 Scan Mode

• In the next step, type the corresponding password, and a "QR code" will appear. Aim the camera on the device towards the code until it makes a "DI" sound, and wait for connection.



STEP 2 Ap Mode

• In the next step, type the corresponding password, then open your phone's "WLAN" settings page. Find and connect to the WIFI network starting with "Wopet_xxx". Finally, go back to the app.

The first of the scale is to share of the scale is to scale is	
WIL • VAR • WAR • WAR • WAR • WAR • WAR • WAR • Ward •	

Manual Feed

• Tap the button to manually pop a treat.



Red Light	Green Light	Product State
OFF	Flashes slowly (Once a second)	Configurable status
OFF	Flashes quickly (Twice a second)	Connecting to the network
OFF	Always on	Network is connected
Flashes slowly	OFF	No food in the grain bucket or the food is blocked

Q: When pressing the "Toss a treat" button, the dog food or snack is tossed two or three times.

A: If the sensor lamp doesn't detect the food, it will toss again, and may toss up to four times.

Q: APP has displayed the prompt for "Dispense excessive food".

A: The snack outlet is blocked; please remove blockage and clean.

Q: APP has displayed the prompt of "No Food".

A: The equipment doesn't sense any fodder in the bucket. Check if the grain bucket has fodder in it; or if the equipment is exposed to direct sunlight, please move it to a cooler place.

Q: The video stream is choppy and/or buffering frequently.

A: Check if the WIFI signal is strong enough, and try to refresh the page on the app.

Q: The user can't enter his/her APP account.

- A: Please check that you are properly connected to the network.
- B: Ensure the account isn't currently being used by another user

Any more questions, please email our support team:



FCC Warnings

Changes or modifications to this unit is not expressly approved.
 Non-compliance could void the user's authority to operate the equipment.

Notes:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur with any particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a different circuit from that to which the receiver is currently connected.
- Consult the dealer or an experienced radio / TV technician for help. Shielded interface cables must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules. Specifications and designs are subject to change without any notice or obligation on the part of the manufacturer.

Warranty Information

1 NON-TRANSFERRABLE LIMITED WARRANTY

① To provide customers with a quality shopping and user experience, we guarantee to replace, issue a refund, provide acceptable solutions to any defective products (as the customers prefers) from the date of purchase up to 2 years.

(2) Proof of purchase must be provided (order number or receipt) when making a claim to our customer support center.

③ Warranty registration may be requested within a month since the date of purchase, by sending your order number to the mailbox: support@wopet.com ④ The warranty is not transferable. We only provide warranty services to buyers who purchased from our Amazon store and WOpet official website store and possess proof of purchase not to any other purchaser or subsequent owner.

(5) Price matching policy is not applicable. No price difference will be refunded.

(6) Sellers are the responsible party. Amazon allows different sellers to sell the same product, so please confirm the seller by checking the order details before contacting us.



- Received defective or used (proof needed) products;
- Received with missing parts;
- Defective item under proper use.

3 What is not Covered

- Purchase from non-amazon channels /non-WOpet official website store/other physical stores;
- Gift without proof of purchase;
- Tampering / abnormal use / accidental damage;
- Replacements and parts;
- Installation fee / labor fee.

4 MAKING A CLAIM

- If you have any problems when using our products, please send an email to the mailbox: support@wopet.com
- 30 days free Return & Replacement
- Standard Warranty: 1-Year product Warranty 2-Year Warranty Application: Please scan the QR code below to finish the registration form on our official website to get 2-Year in total warranty.
- **Note:** Please finish the form within 30 days after you received the items.



Have a Question?

1.Find your order



3.Click the Seller name

View order details Order# Order Total Shipped Product link Qty: 1 Sold By: Seller 2.Click "View order details"



4.Click "Ask a question"

BRAND

Have a question for the seller?

Ask a question

- Gifted parts, replacements, and consumable products are not covered by the 2-year warranty
- Manufactures' warranties may not apply in all cases, depending on factors such as use of the product, where the product was purchased, or who you purchase the product from.
- Please review the warranty carefully, and contact the manufacture if you have any questions.



